SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

DIN Rail Energy Meter (METER-LPB-DIN) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: Panel cut-out 92 x 92 mm (panel type) or 35 mm DIN rail
- Operating temperature: -25 to +55 °C
- Degree of protection: IP51 (front)
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Check CT polarity and phase sequence
2. Set CT and VT ratios
3. Set communication address and baud rate
4. Verify readings against a reference meter

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See

Negative active power reading	CT polarity reversed	TG-METER-LPB-DIN §3.1
No Modbus response	Address / baud / parity mismatch	TG-METER-LPB-DIN §3.2
Pulse output not counted by PLC	Open-collector output polarity reversed	TG-METER-LPB-DIN §3.3

On-site commissioning support can be requested through the Global CS Center. For power & energy meters the request is handled by the technical support team.