SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

VCB 25.8kV 1250A (VCB-25kV-1250) — Datasheet

1. Overview

Vacuum circuit breaker 25.8kV / 1250A, spring operating mechanism. Product family: MV breakers & switchgear. Lifecycle status: **ACTIVE**.

2. Technical specifications

2.1. Ratings

Item	Value
Rated voltage	25.8 kV
Rated normal current	1250 A

2.2. Performance and characteristics

Item	Value
Rated short-circuit breaking current	25 kA
Rated short-time withstand	25 kA / 3 s
Lightning impulse withstand (BIL)	125 kV

2.3. Endurance and communication

Item	Value
Mechanical endurance class	M2 (10,000 operations)
Electrical endurance class	E2

2.4. Protection and options

Item	Value
Spring charging motor voltage	DC 110 V / DC 125 V / AC 220 V

3. Installation data

3.1. Terminals

- Dimensions (W x H x D): 700 x 820 x 650 mm
- Weight: 165 kg
- Degree of protection: IP4X (in panel)
- Operating temperature: -25 to +40 °C

4. Standards and certifications

Applicable standards:

- IEC 62271-100

Certifications held:

- CE
- KEMA type test report

Certificates and declarations of conformity are available from the Certification & Compliance team on request. Certifications not listed above are not held for this product; project-specific evaluation can be requested.

5. Ordering information

Item	Value
Ordering code	VCB-25kV-1250
Standard lead time	12 weeks ex-works
Minimum order quantity	1
Warranty	24 months (see POL-WARRANTY)
Firmware	not applicable

6. Related documents

- IG-VCB-25kV-1250 — Installation and Commissioning Guide
- TG-VCB-25kV-1250 — Troubleshooting and Error Code Guide
- MG-VCB-25kV-1250 — Maintenance Guide
- FAQ-MV_EQUIP — MV breakers & switchgear FAQ

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

VCB 25.8kV 1250A (VCB-25kV-1250) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: 800 mm in front for withdrawal of the circuit breaker truck; 100 mm at the rear unless rear-access type
- Operating temperature: -25 to +40 °C
- Degree of protection: IP4X (in panel)
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Check interlocks (circuit breaker, earthing switch, doors)
2. Perform power-frequency withstand test of the main circuit
3. Check protection relay settings by secondary injection
4. Verify CT polarity and VT ratio
5. Rack in and test closing and opening

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See
VCB spring not charging	Charging motor failure	TG-VCB-25kV-1250 §3.1
VCB fails to close electrically	Closing coil burnt	TG-VCB-25kV-1250 §3.2
VCB contact wear indicator at limit	Vacuum interrupter end of electrical life	TG-VCB-25kV-1250 §3.3
Protection relay trip without fault	CT polarity reversed / wrong relay setting	TG-VCB-25kV-1250 §3.4

On-site commissioning support can be requested through the Global CS Center. For mv breakers & switchgear the request is handled by Field Service.

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

VCB 25.8kV 1250A (VCB-25kV-1250) — Maintenance Guide

1. Maintenance intervals

Task	Interval
Mechanism lubrication	5 years or 2,000 operations
Contact wear check	5 years
Thermographic inspection	12 months
Partial discharge check	12 months

2. Spare parts

- Charging motor
- Closing coil
- Vacuum interrupter

3. End of life

Lifecycle status: ACTIVE. Expected service life is 20 years under normal conditions. Dispose of according to local regulations for electrical equipment.