SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

XGT Panel eXP60 (6") (HMI-XGT-eXP60) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: Panel cut-out per dimension drawing; 50 mm behind the unit for cable bending
- Operating temperature: 0 to +50 °C
- Degree of protection: IP65 (front)
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Check 24 V DC supply polarity
2. Download project with matching editor/OS version
3. Set PLC connection driver and station number
4. Calibrate touch panel

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See

PLC communication timeout on HMI	Driver protocol or station number mismatch	TG-HMI-XGT-eXP60 §3.1
Project download fails	Editor version newer than HMI OS	TG-HMI-XGT-eXP60 §3.2
Touch position misaligned	Touch calibration drift	TG-HMI-XGT-eXP60 §3.3
Logging stops, memory full warning	Logging storage set to internal memory without rotation	TG-HMI-XGT-eXP60 §3.6

On-site commissioning support can be requested through the Global CS Center. For operator panels (hmi) the request is handled by the technical support team.