SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

MCCB 400AF (MCCB-ABS-403c) — Datasheet

1. Overview

Molded case circuit breaker, 400A frame, adjustable thermal-magnetic trip unit. Product family: Low-voltage circuit breakers. Lifecycle status: **ACTIVE**.

2. Technical specifications

2.1. Ratings

Item	Value
Frame size	400AF
Rated current (In)	250, 300, 350, 400 A

2.2. Performance and characteristics

Item	Value
Ultimate breaking capacity Icu at AC 415 V	50 kA
Service breaking capacity Ics	100% of Icu
UL 489 interrupting rating at 480 V (-U variant)	35 kA

2.3. Endurance and communication

Item	Value
Mechanical endurance	7,000 operations

2.4. Protection and options

Item	Value
Thermal trip adjustment	0.8 to 1.0 x In
Magnetic trip adjustment	5 to 10 x In

3. Installation data

3.1. Terminals

- Terminal tightening torque: 18 N·m (M10)
- Dimensions (W x H x D): 140 x 257 x 109 mm
- Weight: 5.2 kg
- Degree of protection: IP20 (front IP40)
- Operating temperature: -5 to +40 °C (derating above 40 °C)

4. Standards and certifications

Applicable standards:

- IEC 60947-2
- UL 489 (-U variant)

Certifications held:

- CE
- CB
- KC
- UL (-U variant)

Certificates and declarations of conformity are available from the Certification & Compliance team on request. Certifications not listed above are not held for this product; project-specific evaluation can be requested.

5. Ordering information

Item	Value
Ordering code	MCCB-ABS-403c
Standard lead time	5 weeks ex-works
Minimum order quantity	5
Warranty	18 months (see POL-WARRANTY)
Firmware	not applicable

6. Related documents

- IG-MCCB-ABS-403c — Installation and Commissioning Guide
- TG-MCCB-ABS-403c — Troubleshooting and Error Code Guide
- MG-MCCB-ABS-403c — Maintenance Guide
- FAQ-LV_BREAKER — Low-voltage circuit breakers FAQ

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

MCCB 400AF (MCCB-ABS-403c) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: 50 mm above and below the breaker for arc gases; 10 mm between adjacent breakers
- Operating temperature: -5 to +40 °C (derating above 40 °C)
- Degree of protection: IP20 (front IP40)
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: 18 N·m (M10)
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Check the rating plate against the single-line diagram
2. Verify tightening torque of all terminals
3. Measure insulation resistance (≥ 5 MΩ at 500 V DC)
4. Operate the breaker manually ON/OFF three times
5. Check trip unit settings against the coordination study

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See
Breaker trips at motor start	Motor inrush exceeds magnetic trip setting	TG-MCCB-ABS-403c §3.1
Terminal overheating / discoloration	Loose connection or undersized cable	TG-MCCB-ABS-403c §3.2
Breaker cannot be reset after trip	Handle not moved to reset position before ON	TG-MCCB-ABS-403c §3.3

On-site commissioning support can be requested through the Global CS Center. For low-voltage circuit breakers the request is handled by the technical support team.

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

MCCB 400AF (MCCB-ABS-403c) — Maintenance Guide

1. Maintenance intervals

Task	Interval
Visual inspection and cleaning	12 months
Terminal torque check	12 months
Manual ON/OFF operation	6 months
Test button (ELCB)	monthly

2. Spare parts

- No user-replaceable parts; replace the complete unit.

3. End of life

Lifecycle status: ACTIVE. Expected service life is 20 years under normal conditions. Dispose of according to local regulations for electrical equipment.