SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

XGT Panel eXP60 (6") (HMI-XGT-eXP60) — Datasheet

1. Overview

6-inch TFT operator panel, 24VDC, Ethernet & serial. Product family: Operator panels (HMI). Lifecycle status: **MATURE**.

2. Technical specifications

2.1. Ratings

Item	Value
Display	6-inch TFT, 800 x 480, 65k colors
Power supply	DC 24 V (19.2-28.8 V)
Front protection	IP65
Backlight life	Approx. 50,000 hours

2.2. Performance and characteristics

Item	Value
User memory	64 MB

2.3. Endurance and communication

Item	Value
Interfaces	Ethernet 1 port, RS-232C, RS-422/485, USB host

3. Installation data

3.1. Terminals

- Dimensions (W x H x D): 184 x 140 x 52 mm
- Weight: 0.9 kg
- Degree of protection: IP65 (front)
- Operating temperature: 0 to +50 °C

4. Standards and certifications

Applicable standards:

- IEC 61131-2

Certifications held:

- CE
- KC

Certificates and declarations of conformity are available from the Certification & Compliance team on request. Certifications not listed above are not held for this product; project-specific evaluation can be requested.

5. Ordering information

Item	Value
Ordering code	HMI-XGT-eXP60
Standard lead time	4 weeks ex-works
Minimum order quantity	1
Warranty	24 months (see POL-WARRANTY)
Firmware	latest 1.62 (see RN-HMI-XGT-eXP60)

6. Related documents

- IG-HMI-XGT-eXP60 — Installation and Commissioning Guide
- TG-HMI-XGT-eXP60 — Troubleshooting and Error Code Guide
- RN-HMI-XGT-eXP60 — Firmware Release Notes
- FAQ-HMI — Operator panels (HMI) FAQ

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

XGT Panel eXP60 (6") (HMI-XGT-eXP60) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: Panel cut-out per dimension drawing; 50 mm behind the unit for cable bending
- Operating temperature: 0 to +50 °C
- Degree of protection: IP65 (front)
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Check 24 V DC supply polarity
2. Download project with matching editor/OS version
3. Set PLC connection driver and station number
4. Calibrate touch panel

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See

PLC communication timeout on HMI	Driver protocol or station number mismatch	TG-HMI-XGT-eXP60 §3.1
Project download fails	Editor version newer than HMI OS	TG-HMI-XGT-eXP60 §3.2
Touch position misaligned	Touch calibration drift	TG-HMI-XGT-eXP60 §3.3
Logging stops, memory full warning	Logging storage set to internal memory without rotation	TG-HMI-XGT-eXP60 §3.6

On-site commissioning support can be requested through the Global CS Center. For operator panels (hmi) the request is handled by the technical support team.

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

XGT Panel eXP60 (6") (HMI-XGT-eXP60) — Firmware Release Notes

1. Summary

Latest firmware: **1.62**. Updating to the latest version is recommended for all units.

2. Version history

2.1. Version 1.62 (2025-10-20)

- Fixed: H.03 project download failure with editor 3.2 or later
- Added: alarm history export to USB as CSV

2.2. Version 1.58 (2025-03-24)

- Fixed: screen freeze after ~30 days continuous uptime

2.3. Version 1.50 (2024-06-10)

- Baseline OS

3. Update procedure

1. Back up parameters / project before updating.
2. Connect the engineering tool (v4.6 or later).
3. Do not switch off power during the update.
4. After the update, verify the version and restore parameters if required.
5. If the update fails, do not power-cycle the unit repeatedly; contact support for the recovery procedure.

4. Compatibility

Parameter files from older versions can be loaded; files from newer versions cannot be loaded into older firmware.