SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

Magnetic Contactor 32A (CONT-MC-32a) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: 10 mm on each side; mount vertically ±30°
- Operating temperature: -25 to +55 °C
- Degree of protection: IP20
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Verify coil voltage against control supply
2. Set the overload relay to motor full load current
3. Check coordination with upstream protective device
4. Test start/stop sequence without load

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See

Contactor chattering	Control voltage drops below pick-up level	TG-CONT-MC-32a §3.1
Contactor coil burnt	Coil voltage different from supply voltage	TG-CONT-MC-32a §3.2

On-site commissioning support can be requested through the Global CS Center. For motor control devices the request is handled by the technical support team.