SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

LSLV H100 22kW VFD (INV-LSLV0220-H100) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: 100 mm above and below, 50 mm on each side; mount vertically for cooling airflow
- Operating temperature: -10 to +50 °C
- Degree of protection: IP20 (IP54 option)
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Enter motor nameplate data (rated power, current, voltage, frequency, speed)
2. Select command source and frequency reference
3. Perform auto-tuning (rotational if possible)
4. Set acceleration/deceleration times for the load
5. Test run at low speed and check rotation direction

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See
Over-current trip during acceleration	Acceleration time too short for load inertia	TG-INV-LSLV0220-H100 §3.1
Over-current trip immediately at run command	Motor cable insulation breakdown (phase-to-phase short)	TG-INV-LSLV0220-H100 §3.2
Over-voltage trip during deceleration	Regenerative energy from load; deceleration time too short	TG-INV-LSLV0220-H100 §3.4
Over-voltage trip at standstill	Supply voltage above tolerance (> 528 V)	TG-INV-LSLV0220-H100 §3.5

On-site commissioning support can be requested through the Global CS Center. For variable frequency drives the request is handled by the technical support team.