SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

Online UPS 10kVA (UPS-LSU-10K) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: 300 mm at the rear and 100 mm on each side for ventilation
- Operating temperature: 0 to +40 °C
- Degree of protection: IP20
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Check battery polarity and voltage
2. Connect input and close input breaker
3. Run self-test
4. Perform battery test
5. Transfer load from bypass to inverter

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See
Short backup time	Battery end of life (> 3 years)	TG-UPS-LSU-10K §3.1
UPS on bypass due to overload	Connected load exceeds rating	TG-UPS-LSU-10K §3.2
Over-temperature alarm	Fan failure	TG-UPS-LSU-10K §3.4
SNMP card not detected	Firmware defect after hot-swap	TG-UPS-LSU-10K §3.5

On-site commissioning support can be requested through the Global CS Center. For uninterruptible power supplies the request is handled by the technical support team.