SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

Thermal Overload Relay 22A (RELAY-GMR-22) — Datasheet

1. Overview

Thermal overload relay up to 22A, phase-loss sensitive, trip class 10A. Product family: Motor control devices. Lifecycle status: **ACTIVE**.

2. Technical specifications

2.1. Ratings

Item	Value
Current setting ranges	0.1-0.16 A up to 16-22 A (13 ranges)
Trip class	Class 10A
Phase-loss sensitivity	Yes (differential mechanism)

2.2. Performance and characteristics

Item	Value
Reset mode	Manual / automatic selectable
Ambient temperature compensation	-25 to +55 °C

3. Installation data

3.1. Terminals

- Dimensions (W x H x D): 45 x 78 x 90 mm
- Weight: 0.15 kg
- Degree of protection: IP20
- Operating temperature: -25 to +55 °C (compensated)

4. Standards and certifications

Applicable standards:

- IEC 60947-4-1

Certifications held:

- CE
- KC
- UL

Certificates and declarations of conformity are available from the Certification & Compliance team on request. Certifications not listed above are not held for this product; project-specific evaluation can be requested.

5. Ordering information

Item	Value
Ordering code	RELAY-GMR-22
Standard lead time	3 weeks ex-works
Minimum order quantity	20
Warranty	18 months (see POL-WARRANTY)
Firmware	not applicable

6. Related documents

- IG-RELAY-GMR-22 — Installation and Commissioning Guide
- TG-RELAY-GMR-22 — Troubleshooting and Error Code Guide
- MG-RELAY-GMR-22 — Maintenance Guide
- FAQ-CONTROL — Motor control devices FAQ

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

Thermal Overload Relay 22A (RELAY-GMR-22) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: 10 mm on each side; mount vertically ±30°
- Operating temperature: -25 to +55 °C (compensated)
- Degree of protection: IP20
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Verify coil voltage against control supply
2. Set the overload relay to motor full load current
3. Check coordination with upstream protective device
4. Test start/stop sequence without load

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See

Overload relay nuisance trip	Setting lower than motor full load current	TG-RELAY-GMR-22 §3.1
Overload relay trips on phase loss	Upstream fuse blown on one phase	TG-RELAY-GMR-22 §3.3

On-site commissioning support can be requested through the Global CS Center. For motor control devices the request is handled by the technical support team.

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

Thermal Overload Relay 22A (RELAY-GMR-22) — Maintenance Guide

1. Maintenance intervals

Task	Interval
Contact inspection	12 months
Coil voltage check	12 months
Overload relay trip test	12 months

2. Spare parts

- No user-replaceable parts; replace the complete unit.

3. End of life

Lifecycle status: ACTIVE. Expected service life is 20 years under normal conditions. Dispose of according to local regulations for electrical equipment.