COPY

Copy pictures between a card in the first slot, a card in the second slot, and an SSD connected to the USB connector.

1 Select **COPY** in the playback menu.

2 Highlight one of the following options.

Option	Description
SSD ➡ SLOT1	Copy pictures from the SSD to the card in the first slot.
SSD ➡ SLOT2	Copy pictures from the SSD to the card in the second slot.
SLOT1 ➡ SSD	Copy pictures from the card in the first slot to the SSD.
SLOT1 ➡ SLOT2	Copy pictures from the card in the first slot to the card in the second slot.
SLOT2 ➡ SSD	Copy pictures from the card in the second slot to the SSD.
SLOT2 ➡ SLOT1	Copy pictures from the card in the second slot to the card in the first slot.

3 Press the focus stick (focus lever) right.

4 Highlight one of the following options and press **MENU/OK**.

Option	Description
FRAME	Copy selected pictures. Press the focus stick left or right to view pictures and press **MENU/OK** to copy the current picture.
ALL FRAMES	Copy all pictures.

Q • Copying ends when the destination is full.
  • If you attempt to copy a file over 4 GB in size to a memory card with a capacity of 32 GB or less, copying will end and the file will not be copied.