-Battery Level-

When a vertical battery grip is connected, the camera battery level display shows the camera battery level and the level of the batteries inserted in the VG-GFX100II.



- The display shows the level of inserted batteries only.
- When a full complement of batteries are inserted in the camera and the VG-GFX100II, the batteries will be used in the following order:
 - 1 The left grip battery (L)
 - $\ensuremath{\text{\textbf{2}}}$ The right grip battery $\ensuremath{\text{\textbf{R}}})$
 - 3 The camera battery