Printing Pictures

- 1 Turn the printer on.
- Select □ PLAY BACK MENU > instax
 Instax Instance PRINTER PRINTER PRINTER PRINTER PRINTER PRINTER PRINTER PRINT. The camera will connect to the printer.



3 Use the focus stick (focus lever) to instance printer print display the picture you want to print, then press MENU/OK.



- Pictures taken with other cameras cannot be printed.
 - The area printed is smaller than the area visible in the LCD monitor.
 - The displays may vary depending on the printer connected.
- 4 The picture will be sent to the printer and printing will start.