The Playback Menu

Adjust playback settings.



See page 179 for details.

| Þ | PLAY BACK MENU | |
|-----|--------------------|-----|
| 1/3 | RAW CONVERSION | 179 |
| | ERASE | 182 |
| | CROP | 184 |
| | RESIZE | 185 |
| | PROTECT | 186 |
| | IMAGE ROTATE | 187 |
| | RED EYE REMOVAL | 188 |
| | VOICE MEMO SETTING | 189 |

| Ь | PLAY BACK MENU | |
|-------------|------------------------|-----|
| 2 /3 | RATING | 190 |
| | IMAGE TRANSFER ORDER | 191 |
| | WIRELESS COMMUNICATION | 192 |
| | SLIDE SHOW | 192 |
| | PHOTOBOOK ASSIST | 193 |
| | PC AUTO SAVE | 194 |
| | PRINT ORDER (DPOF) | 195 |
| | instax PRINTER PRINT | 196 |
| 3∕₃ | DISP ASPECT | 197 |
| | | |