4 Available only if **FOCUS CHECK** is assigned to a function button.

5 Exposure compensation dial rotated to **C** or **ON** selected for **MOVIE OPTIMIZED CONTROL** ⊜ **▶**.

6 Can be used to switch back and forth between aperture, sensitivity, and exposure compensation when exposure compensation dial is rotated to **C** or **ON** is selected for **MOVIE OPTIMIZED CONTROL** ⊜ **▶**.

N The rotation direction for the command dials can be selected using **⚙ BUTTON/DIAL SETTING** > **COMMAND DIAL DIRECTION**.