## Customizing the Standard Display

To choose the items shown in the standard indicator display:

- Display standard indicators.
   Use the DISP/BACK button to display standard indicators.
- 2 Select DISP. CUSTOM SETTING. Select SCREEN SET-UP > DISP. CUSTOM SETTING in the setup menu.
- 3 Choose items.
  Highlight items and press MENU/OK to select or deselect.

5 5	•		
ltem	Default	ltem	Default
FRAMING GUIDELINE		CONTINUOUS MODE	✓
ELECTRONIC LEVEL		DUAL IS MODE	✓
FOCUS FRAME	<b>V</b>	TOUCH SCREEN MODE	✓
AF DISTANCE INDICATOR		WHITE BALANCE	✓
MF DISTANCE INDICATOR	<b>V</b>	FILM SIMULATION	✓
HISTOGRAM		DYNAMIC RANGE	✓
LIVE VIEW HIGHLIGHT ALERT		BOOST MODE	<b>V</b>
SHOOTING MODE	<b>V</b>	FRAMES REMAINING	<b>V</b>
APERTURE/S-SPEED/ISO	<b>V</b>	IMAGE SIZE/QUALITY	✓
INFORMATION BACKGROUND	<b>V</b>	MOVIE MODE & REC. TIME	✓
Expo. Comp. (Digit)		IMAGE TRANSFER ORDER	✓
Expo. Comp. (Scale)	<b>V</b>	MIC LEVEL	<b>V</b>
FOCUS MODE	<b>V</b>	GUIDANCE MESSAGE	✓
PHOTOMETRY	<b>V</b>	BATTERY LEVEL	✓
SHUTTER TYPE	<b>V</b>	FRAMING OUTLINE	
FLASH	<b>V</b>	-	'

- 4 Press DISP/BACK to save changes.
- 5 Press DISP/BACK as needed to exit the menus and return to the shooting display.