
SELECT CUSTOM SETTING.

The MIMAGE QUALITY SETTING > SELECT CUSTOM SETTING item (item

- 1) shows the current custom settings bank:
- BASE: No custom settings bank selected.
- C 1–C7: Select a bank to view the settings saved using the
 ☐ IMAGE QUALITY SETTING > EDIT/SAVE CUSTOM SETTING option.
- 🚰 🕰: The current custom settings bank.

Viewing and Changing Settings

1 Press **Q** to display the quick menu during shooting.



- **2** Use the focus stick (focus lever) to highlight items and rotate the rear command dial to change.
 - Changes are not saved to the current settings bank.
 - Settings that differ from those in the current settings bank (C1-C7) are shown in red.





- 3 Press **Q** to exit when settings are complete.
- The quick menu can also be edited using touch controls.