2 Choose the desired network/USB settings.



- To use any of the following pre-existing connection setting profiles, choose **SELECT CONNECTION SETTING**.
 - 1: UNIVERSAL SETTING
 - 2: USB CARD READER
 - 3: USB TETHER SHOOTING AUTO
 - 4: USB TETHER SHOOTING FIXED
 - 5: USB RAW CONV./BACKUP RESTORE
 - 6: USB WEBCAM
- 3 Select CREATE NEW. Choosing a tethered photography option displays the options shown. To create a new profile, select CREATE NEW.



- 4 Adjust network/USB settings.
 For more information, refer to the section on the setting in question.
 - "Tethered Photography" (260)
 - "Uploading Pictures via FTP" (278)
 - "Remote Movie Recording Using a Web Browser" (🕮 293)
- Saved connection setting profiles are marked by icons indicating the communication setting profile.