

POWER MANAGEMENT

Adjust power management settings.

To access power management settings, press MENU/OK, select the (SET UP) tab, and choose POWER MANAGEMENT.



AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually.

Options					
5 MIN	2 MIN	1 MIN	30 SEC	15 SEC	OFF

PERFORMANCE

Select **BOOST** to improve focus and viewfinder display performance.

	Option	Description
		Boost camera focus and viewfinder display performance. The
	БООЗТ	battery drains faster than when is NORMAL selected.
	NORMAL	Choose for standard focus and viewfinder display performance
	NONWAL	and battery endurance.