## Connecting via Wired LAN (Ethernet)

Create a connection setting profile for use when connecting the camera to a computer or tablet via wired LAN (Ethernet).

- 1 Select CREATE/EDIT CONNECTION SETTING > CREATE USING WIZARD in the network/USB setting menu and choose REMOTE REC FUNCTION.
- 2 Select CREATE NEW.
  - Choose SELECT FROM LIST to select from a list of existing connection setting profiles.



REMOTE REC FUNCTION

3 Press MENU/OK when prompted.



4 Select WIRED LAN.



**5** Select **CREATE NEW** to create a new communication setting profile.



