D EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu during still photography (1 311).

EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu when filming movies (19 311).

FUNCTION (Fn) SETTING

Choose the roles played by the function buttons (19 317).

POWER ZOOM LENS FUNCTION (Fn) SETTING

Choose the roles played by the function buttons available on some power zoom lenses (325).