5 Press MENU/OK.

The combined exposures will be displayed as a guide to composing the next shot.





- To return to the previous step and retake the second shot, press the focus stick left.
 - To end shooting and create a multiple exposure from the shots taken to this point, press DISP/BACK.
- 6 Make additional exposures. Each photograph can contain up to nine exposures.
- 7 Press DISP/BACK to end shooting. The camera will create the combined image and multiple exposure shooting will end.
- Use **SHOOTING SETTING** > **MULTIPLE EXPOSURE CTRL** to choose how the exposures are combined.