## **Q MENU BACKGROUND**

Choose the background color used for the quick menu when it is displayed during still photography.

Options	
TRANSPARENT	BLACK

## **PORTON OF THE PROPERTY OF THE PARK OF THE**

Choose the background color used for the quick menu when it is displayed during movie recording.

Options	
TRANSPARENT	BLACK