Shortcuts	375
Shortcut Options	376
MY MENU	377
MY MENU SETTING	377
The Quick Menu	379
The Quick Menu Display	379
Viewing and Changing Settings	381
Editing the Quick Menu	382
Function Controls	385
The Function Buttons	385
Touch-Function Gestures	390
Peripherals and Optional Accessories	393
Lenses	394
Lens Parts	
Lens Care	
Removing Lens Caps	
Attaching Lens Hoods	395
Aperture Rings	396
T/S Lenses	
Viewfinder Tilt Adapters	
Attaching the EVF-TL1	398
Using the EVF-TL1	399
External Flash Units	400
Flash Settings	401
SYNC TERMINAL	402
SHOE MOUNT FLASH	403
COMMANDER(OPTICAL)	406
Vertical Battery Grips	410
Attaching the Vertical Battery Grip	411
Inserting and Removing Batteries	413
Charging the Batteries	415
Cooling Fans	416
Attaching a Cooling Fan	416
Using the Fan	418