

AF/MF SETTING (Still Photography)

Adjust focus settings for still photography.

To display AF/MF settings, press **MENU/OK** in the photo shooting display and select the **M** (**AF/MF SETTING**) tab.





The options available vary with the shooting mode selected.

FOCUS AREA

Choose the focus area for autofocus, manual focus, and focus zoom (1997).

FOCUS MODE

Choose how the camera focuses (\$\square\$ 69).

AF MODE

Choose how the camera focuses in modes Es and E (\$\mathbb{E}\$ 71).