The Playback Menu

Adjust playback settings.



See page 187 for details.

Þ	PLAY BACK MENU	
1/3	RAW CONVERSION	187
	ERASE	190
	CROP	192
	RESIZE	193
	PROTECT	194
	IMAGE ROTATE	195
	RED EYE REMOVAL	196
	VOICE MEMO SETTING	197

Þ	PLAY BACK MENU	
2 /3	RATING	198
	IMAGE TRANSFER ORDER	199
	★ WIRELESS COMMUNICATION	200
	SLIDE SHOW	200
	PHOTOBOOK ASSIST	201
	PC AUTO SAVE	202
	PRINT ORDER (DPOF)	203
	instax PRINTER PRINT	204
3/3	DISP ASPECT	205