2 First Steps	29
Attaching the Strap	30
Inserting the Battery and a Memory Card	32
Compatible Memory Cards	
Charging the Battery	
Turning the Camera On and Off	
Checking the Battery Level	
Basic Setup	
Choosing a Different Language	
Changing the Time and Date	42
Basic Photography and Playback	43
Taking Photographs (Mode P)	
Viewing Pictures	
Deleting Pictures	48
Movie Recording and Playback	49
Recording Movies	50
Adjusting Movie Settings	
Viewing Movies	53
5 Taking Photographs	55
P, S, A, and M Modes	56
Mode P: Program AE	56
Mode S: Shutter-Priority AE	
Mode A: Aperture-Priority AE	62
Mode M: Manual Exposure	
Autofocus	
Focus Mode	
Autofocus Options (AF Mode)	
Focus-Point Selection	
Manual Focus	
Checking Focus	
Sensitivity Auto Sensitivity (A)	
Metering	
The Digital Teleconverter	
The Digital Teleconverter	00