Customizing the Standard Display	21
Virtual Horizon	23
Using the Menus	24
The Menus	24
Selecting a Menu Tab	25
Touch Screen Mode	26
Shooting Touch Controls	26
Playback Touch Controls	
2 First Steps	33
Attaching the Strap	34
Attaching a Lens	35
Inserting the Battery	36
Inserting Memory Cards	
Using Two Cards	
Compatible Memory Cards	
Charging the Battery	
Turning the Camera On and Off	
Checking the Battery Level	
Basic Setup	
Choosing a Different Language	
Changing the Time and Date	50
Basic Photography and Playback	51
Taking Photographs (Mode P)	
Viewing Pictures	
HDMI Output	
Deleting Pictures	59
4 Movie Recording and Playback	61
Recording Movies	62
Recording Movies	62
Adjusting Movie Settings	68
Viewing Movies	69