The Playback Menu

Adjust playback settings.



See page 225 for details.

Þ	PLAY BACK MENU	
1⁄2	RAW CONVERSION	225
	HEIF TO JPEG/TIFF CONVERSION	228
	ERASE	229
	CROP	231
	RESIZE	232
	PROTECT	233
	IMAGE ROTATE	234
	VOICE MEMO SETTING	235

Þ	PLAY BACK MENU	
2 ⁄2	RATING	236
	TRANSFER IMAGE TO SMARTPHONE	237
	₩ WIRELESS COMMUNICATION	239
	SLIDE SHOW	239
	PHOTOBOOK ASSIST	240
	PRINT ORDER (DPOF)	242
	instax PRINTER PRINT	243
	DISP ASPECT	244