

Taking Photographs (Mode P)

This section describes how to take pictures using program AE (mode P). See pages 72–81 for information on S, A, and M modes.

1 Rotate the STILL/MOVIE mode dial to STILL.



2 Slide the lens aperture mode switch to **A**.



- 3 Rotate the shutter speed dial to A.
 - To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.



P will appear in the display.

