Setup Menus

Adjust basic camera settings.



See page 207 for details.

۶	USER SETTING	
1/2	FORMAT	208
	DATE/TIME	209
	TIME DIFFERENCE	209
	■ 言語/LANG.	210
V2	MY MENU SETTING	210
	🗯 MY MENU SETTING	210
	SENSOR CLEANING	211
	SOUND & FLASH	211
2 /2	RESET	212
4 2	REGULATORY	212
۶	SOUND SETTING	
A	F BEEP VOL.	213
SELF-TIMER BEEP VOL.		213
OPERATION VOL.		214
SHUTTER VOLUME 214		
SI	HUTTER SOUND	214
P	LAYBACK VOLUME	214

۶	SCREEN SETTING	
1/3	VIEW MODE SETTING	215
	EVF BRIGHTNESS	215
	EVF COLOR	215
	EVF COLOR ADJUSTMENT	216
	LCD BRIGHTNESS	216
	LCD COLOR	216
	LCD COLOR ADJUSTMENT	216
	IMAGE DISP.	217
2 /3	AUTOROTATE DISPLAYS	217
	PREVIEW EXP./WB IN MANUAL MODE	218
	NATURAL LIVE VIEW	218
	F-Log VIEW ASSIST	219
	FRAMING GUIDELINE	219
	AUTOROTATE PB	220
	FOCUS SCALE UNITS	220
	APERTURE UNIT FOR CINEMA LENS	220
3 ⁄3	DISP. CUSTOM SETTING	220
	LARGE INDICATORS MODE(EVF)	221
	LARGE INDICATORS MODE(LCD)	221
	LARGE INDICATORS DISP. SETTING	222
	INFORMATION CONTRAST ADJ.	222
	Q MENU BACKGROUND	223
	🕰 Q MENU BACKGROUND	223