TILT 🌣

Option	Description
OFF	Pressing the stick up, down, left, or right has no effect.
DIRECT AF POINT SELECTION	Choose the focus area without leaving the shooting display.
EDIT FOCUS AREA	Press the stick up, down, left, or right to view a focus-area display and choose the focus area.
DIRECT AF POINT SELECTION/FACE SELECT	Choose the focus area without leaving the shooting display. If FACE DETECTION ON is selected for FACE/EYE DETECTION SETTING , you can also choose the face used for focus.

D EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu during still photography (12) 250).

EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu when filming movies (\$\exists 250\$).

FUNCTION (Fn) SETTING

Choose the roles played by the function buttons (253).