The Dual Display	24
Customizing the Standard Display	25
Virtual Horizon	27
The Secondary LCD Monitor	28
Using the Menus	32
The Menus	32
Selecting a Menu Tab	
Touch Screen Mode	
Shooting Touch Controls	
Playback Touch Controls	38
2 First Steps	39
Attaching the Strap	40
Attaching a Lens	
Inserting the Battery	43
Inserting Memory Cards	45
Using Two Cards	
Compatible Memory Cards	
Using an external SSD in place of a memory card	
Charging the Battery	
Turning the Camera On and Off	
Checking the Battery Level	
Basic Setup	
Choosing a Different Language	
Changing the Time and Date	58
Basic Photography and Playback	59
Taking Photographs (Mode P)	60
Viewing Pictures	63
HDMI Output	64
Deleting Pictures	66
4 Movie Recording and Playback	67
Recording Movies	
Adjusting Movie Settings	72
Viewing Movies	73