

SHOOTING SETTING (Still Photography)

Adjust shooting options for still photography.

To display shooting settings, press MENU/OK in the photo shooting display and select the (SHOOTING SETTING) tab.



The options available vary with the shooting mode selected.



DRIVE SETTING

Adjust settings for the various drive modes.

BKT SETTING

Choose the bracketing type and adjust bracketing options for the BKT drive mode.

BKT SELECT

The following options are available when **BKT** is selected for drive mode.

Bracketing type	
🔁 AE BKT	WHITE BALANCE BKT
SSSI ISO BKT	DEN DYNAMIC RANGE BKT
□ FILM SIMULATION BKT	FOCUS BKT