	2 First Steps	27
	Attaching the Strap	28
	Attaching a Lens	29
	Inserting the Battery and a Memory Card	30
	Compatible Memory Cards	
	Charging the Battery	
	Turning the Camera On and Off	
	Checking the Battery Level	
	Basic Setup	
	Choosing a Different Language	
	Changing the Time and Date	39
	Basic Photography and Playback	41
ı	Taking Photographs (Mode P)	42
	Viewing Pictures	
	Deleting Pictures	
į		
	4 Movie Recording and Playback	47
	Recording Movies	
	Recording Movies	
	Adjusting Movie Settings	
	Viewing Movies	52
	5 Taking Photographs	55
	P, S, A, and M Modes	56
	Mode P: Program AE	
	Mode S: Shutter-Priority AE	
	Mode A: Aperture-Priority AE	
	Mode M: Manual Exposure	
	Front Command Dial Roles by Mode	
	Autofocus	
	Focus Mode Autofocus Options (AF Mode)	
	Focus-Point Selection	
	Manual Focus	
	Checking Focus	