

BUTTON/DIAL SETTING

Access options for camera controls.

To access control options, press MENU/OK, select the ☑ (SET UP) tab, and choose BUTTON/DIAL SETTING.



FOCUS LEVER SETTING

Choose the functions performed by the focus stick (focus lever).

Option	Description
LOCK (OFF)	The focus stick cannot be used during shooting.
	Press the stick to view the focus-point display and tilt the stick
	to select a focus point.
ON	Tilt the stick to view the focus-point display and select a focus
	point.