PRE-SHOT ES A

To reduce the lag between your pressing the shutter button all the way down and the resulting picture being recorded to the memory card, the camera starts shooting with the electronic shutter when the shutter button is pressed halfway and saves a series shots starting just before the shutter button is pressed the rest of the way down.

Options	
ON	OFF



Pre-shot photography is available only when **ES ELECTRONIC SHUTTER** is selected in **CH** (high speed burst) drive mode (146).

SELF-TIMER

Choose a shutter release delay.

Use to reduce blur caused by the camera moving when the shutt button is pressed. The self-timer lamp blinks as the timer cour	Option	Description
button is pressed. The self-timer lamp blinks as the timer cour		The shutter is released two seconds after the shutter button is pressed.
button is pressed. The self-timer lamp blinks as the timer cour	%) 2 CFC	Use to reduce blur caused by the camera moving when the shutter
down	C ₂ 2 3EC	button is pressed. The self-timer lamp blinks as the timer cou
down.		down.
The shutter is released ten seconds after the shutter button is presse		The shutter is released ten seconds after the shutter button is pressed.
Use for photographs in which you wish to appear yourself. The self-timer lamp blinks immediately before the picture is taken.		Use for photographs in which you wish to appear yourself. The
self-timer lamp blinks immediately before the picture is taken.		self-timer lamp blinks immediately before the picture is taken.
OFF Self-timer off.	OFF	Self-timer off.