COLOR

Adjust color density. Choose higher values to increase saturation, lower values to reduce it.

Options								
−4	−3	−2	−1	0	+1	+2	+3	+4

SHARPNESS

Sharpen or soften outlines. Choose higher values for sharper outlines, lower values for softer outlines.

Options								
−4	−3	−2	−1	0	+1	+2	+3	+4

HIGH ISO NR

Reduce noise in pictures taken at high sensitivities. Choose higher values to reduce noise and smooth outlines, lower values to leave outlines visible.

Options								
−4	−3	−2	−1	0	+1	+2	+3	+4

6

The Shooting Menus