

## **IMAGE QUALITY SETTING (Still Photography)**

Adjust image quality settings for still photography.

To display image quality settings, press MENU/OK in the photo shooting display and select the (IMAGE QUALITY SETTING) tab.





The options available vary with the shooting mode selected.

## **IMAGE SIZE**

Choose the size and aspect ratio at which still pictures are recorded.

Option	lmage size	Option	lmage size
4:3	11648 × 8736	65:24	11648 × 4304
3:2	11648 × 7768	5:4	10928 × 8736
16:9	11648 × 6552	7:6	10192 × 8736
<b>P</b> 1:1	8736 × 8736		

Option	lmage size	Option	lmage size
M 4:3	8256 × 6192	M 65:24	8256 × 3048
M 3:2	8256 × 5504	M 5:4	7744×6192
₩ 16:9	8256 × 4640	M 7:6	7232×6192
M 1:1	6192 × 6192		

Option	lmage size	Option	lmage size
\$ 4:3	4000 × 3000	<b>S</b> 65:24	4000 × 1480
\$ 3:2	4000 × 2664	S 5:4	3744×3000
\$ 16:9	4000 × 2248	\$ 7:6	3504×3000
§ 1:1	2992 × 2992		



MAGE SIZE is not reset when the camera is turned off or another shooting mode is selected.