| Cotting | Description |
|-----------------------|---|
| Setting | Description |
| ① Commander | Choose the group for units functioning as a command- |
| | er for Fujifilm optical wireless remote flash control in TTL , |
| | TTL%, or M mode. This option is available only with clip- |
| | on flash units that support Fujifilm optical wireless remote |
| | flash control. |
| | • Gr A : Assign the commander to group A. |
| | • Gr B : Assign the commander to group B. |
| | • Gr C : Assign the commander to group C. |
| | • 0FF : Output from the commander is held to a level that |
| | does not affect the final picture. |
| 11) Number of flashes | Choose the number of times the flash fires each time the |
| | shutter is released in MULTI mode. |
| (12) Channel | Choose the channel used by the commander for commu- |
| | nication with the remote flash units. Separate channels |
| | can be used for different flash systems or to prevent in- |
| | terference when multiple systems are operating in close |
| | proximity. |
| 12) Frequency | Choose the frequency at which the flash fires in MULTI |
| | mode. |