

Default	
① ₩ SELECT CUSTOM SETTING*	(5) APERTURE (MOVIE OPTIMIZED CONTROL → ▶)
② S.S. (MOVIE OPTIMIZED CONTROL ■ •)	⑥ ISO (MOVIE OPTIMIZED CONTROL → ►)
3 MOVIE MODE RESOLUTION/ ASPECT RATIO	7 MOVIE MODE FRAME RATE
④ ₩ WHITE BALANCE	8 ₩ WHITE BALANCE COLOR TEMP. (WHEN ☑ SELECTED)

^{*} If no settings bank is currently selected for **# SELECT CUSTOM SETTING**, the shooting mode will be displayed instead.

The quick menu shows the options currently selected for items (2)–(8), which can be changed.