Q MENU BACKGROUND

Choose TRANSPARENT for a transparent background.

Options	
TRANSPARENT	BLACK

FUNCTION (Fn) SETTING

Choose the roles played by the function buttons.

- 1 Select BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING in the ► (SET UP) tab.
- 2 Highlight the desired control and press MENU/OK.
- 3 Highlight any of the following options and press MENU/OK to assign it to the selected control.
- AE LOCK ONLY, AF LOCK ONLY, AE/AF LOCK, AF-ON, and AWB LOCK ONLY cannot be assigned to the touch function buttons (T-Fn1 through T-Fn4) or to the viewfinder selector (rotate and hold).
 - Function button assignment options can also be accessed by holding the DISP/BACK button.