Warning	Description
WRITE ERROR	 Memory card error or connection error: Reinsert the card or
	turn the camera off and then on again. If the message
	persists, contact a Fujifilm dealer.
	 Not enough memory remaining to record additional pictures:
	Delete pictures or insert a memory card with more free
	space.
	 The memory card is not formatted: Format the memory card.
FRAME NO. FULL	The camera has run out of frame numbers (current frame
	number is 999-9999). Insert a formatted memory card and
	select RENEW for SAVE DATA SET-UP > FRAME NO.
	Take a picture to reset frame numbering to 100-0001, then
	select CONTINUOUS for FRAME NO. .
READ ERROR	• The file is corrupt or was not created with the camera: The file
	cannot be viewed.
	• The memory card contacts require cleaning: Clean the con-
	tacts with a soft, dry cloth. If the message is repeated,
	format the card. If the message persists, replace the card.
	Camera malfunction: Contact a Fujifilm dealer.
PROTECTED FRAME	An attempt was made to delete or rotate to a protected pic-
	ture. Remove protection and try again.
CAN NOT CROP	The picture is damaged or was not created with the camera.
DPOF FILE ERROR	Print orders can contain no more than 999 pictures. Copy
	any additional pictures you wish to print to another memo-
	ry card and create a second print order.
CAN NOT SET DPOF	The picture cannot be printed using DPOF.
CAN NOT SET DPOF	Movies cannot be printed using DPOF.
CAN NOT ROTATE	The selected picture cannot be rotated.
CAN NOT ROTATE	Movies cannot be rotated.
CANNOT EXECUTE	Red-eye removal cannot be applied to movies.
台 CANNOT EXECUTE	Red-eye removal cannot be applied to pictures created
	with other devices.
MISMATCH: 4K MODE	The movie mode selected with the camera is not compat-
	ible with the device to which the camera is connected via
CHANGE MOVIE MODE	HDMI. Try selecting a different movie mode (🕮 155).