

## AF/MF SETTING (Movie Recording)

Adjust focus settings for movies.

To display AF/MF settings, press MENU/OK in the movie shooting display and select the M (AF/MF SETTING) tab.





The options available vary with the shooting mode selected.

## 🗯 FOCUS AREA

Choose the focus area for autofocus, manual focus, and focus zoom ( 87).



The focus area cannot be resized while recording is in progress.

## 🗯 AF MODE

Choose how the camera selects the focus point for movie recording.

Option	Description
MULTI	The camera selects the focus area automatically.
AREA	The camera focuses on the subject in the selected focus area.