TOUCH SCREEN SETTING

Enable or disable touch-screen controls.

Option	Description
TOUCH SCREEN SETTING	 ON: The LCD monitor functions as a touch screen during shooting. OFF: Touch controls disabled.
DOUBLE TAP SETTING	 ON: Tap the LCD monitor twice to zoom in on your subject during shooting. OFF: Touch zoom disabled.
TEN TOUCH FUNCTION	Enable or disable touch function gestures.
TOUCH SCREEN SETTING	 ON: The LCD monitor functions as a touch screen during playback. OFF: Touch controls disabled.
EVF/OVF TOUCH SCREEN AREA SETTINGS	Select the area of the LCD monitor used for touch controls while the viewfinder is active. The area used for touch controls can be selected from: [Insert a left half] Insert a left quarter) Insert a left quarter Insert a lef