

Maintenance

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	Fastening	■ Fasten	Р	Υ
	 Damage 	■ Replace	Р	М
	(condition)	■ Repair		ı
	- Function	Repair	N	S
	 Unusual noises 	Eliminate the cause	Ν	М
	• Wear	Replace	Р	М
		■ Repair		İ
	Contamination	- Clean	Р	М
Sliding blocks,	- Damage	- Replace	Р	3M
springs, rolls	Spring force	Repair		
	• Wear			
Cylinder	Function	- Replace	Ν	S
		 Repair 		ĺ
		Set speed		
	 Bearing assembly 	Fasten	Р	6M
		Replace		l



Maintenance

Area	Inspection	Action	ОС	TI
		■ Repair		
	• Seal	■ Replace	Р	3M
		■ Repair		
Fluid line,	• Leaks	- Replace	Р	М
fluid connection		■ Repair		
	Volumetric flow rate	Set volumetric flow rate	N	М

Operating condition (OC)

Normal operation (production)

P Stop (maintenance, troubleshooting)

Time interval (TI)

S every shift (8 hours)

**)M every month

**)Y every year

**) Intervals combined with numbers signify for example:

3M= every three months

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.