

## Maintenance

## 7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
Signals	Functioning	Repair	N	3M
	<ul><li>Settings</li></ul>			
Conditioning unit	Contamination	- Clean	N	М
Fan	Functioning	Repair	N	D
	<ul><li>Leaks</li></ul>	■ Replace		
	<ul><li>Impeller</li></ul>	Repair	N	М
Fluid line,	- Leaks	- Replace	Р	М
fluid connection		■ Repair		
	Volumetric flow rate	Set volumetric flow rate	N	М
Cables	Damage	Repair	N	D
	<ul><li>Fastenings</li></ul>	- Replace		
		■ Fasten		

Operating condition (OC)		
N	Normal operation (production)	

P Stop (maintenance, troubleshooting)

## Time interval (TI)

\*\*)D every day (24 hours)

\*\*)M every month

\*\*) Intervals combined with numbers denote for example:

3M= every three months

## **NOTICE**

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.

AISHA-CCM Version: A - 2018-10-25 15