

Maintenance

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	 Fastening 	■ Fasten	Р	Υ
	Damage	- Replace	Р	М
	(condition)	- Repair		İ
	Function	Repair	N	S
	 Unusual noises 	Eliminate the cause	N	М
	• Wear	Replace	Р	М
		- Repair		ĺ
	Contamination	- Clean	Р	М
Pinch and bending	Function	Repair	Р	ЗМ
roll	■ Wear	■ Replace		
	Scoring	Repair	Р	W
Cylinder	Function	- Replace	Ν	S
		 Repair 		ĺ
		Set speed		
	 Bearing assembly 	Fasten	Р	6M
		Replace		l

AISHA-CCM Version: A - 2018-10-10 13



Pinch and bending roll

Maintenance

Area	Inspection	Action	ОС	TI
		 Repair 		
	• Seal	■ Replace	Р	W
		■ Repair		
Fluid line,	• Leaks	- Replace	Р	М
fluid connection		■ Repair		
	Volumetric flow rate	Set volumetric flow rate	N	М
Limit switch	Function	- Adjust	Z	М
		■ Replace		
		■ Repair		

Operating condition (OC)		Time interval (TI)		
N	Normal operation (production)	S	every shift (8 hours)	
Р	Stop (maintenance, troubleshooting)	**)W	every week	
Z	Enabling mode	**)M	every month	
		**)Y	every year	
		**) Intervals combined with numbers signify for example:		
		3M= every three months		

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.