

Spindle head support

## Maintenance

## 7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	<ul> <li>Fastening</li> </ul>	<ul> <li>Fasten</li> </ul>	Р	Υ
	<ul> <li>Damage</li> </ul>	■ Replace	Р	M
	(condition)	■ Repair		
	• Function	<ul> <li>Repair</li> </ul>	N	S
	<ul> <li>Unusual noises</li> </ul>	Eliminate the cause	N	М
	• Wear	■ Replace	Р	W
		■ Repair		
	<ul> <li>Contamination</li> </ul>	■ Clean	Р	W
Guide	Centralized	Top up	Р	W
	lubrication	<ul> <li>Adjust</li> </ul>		
		<ul> <li>Adapt</li> </ul>		
	• Wear	- Replace	Р	W
		<ul> <li>Repair</li> </ul>		
Bushes	■ Wear	■ Replace	Р	W
		<ul> <li>Repair</li> </ul>		
Hydraulic cylinders	• Function	■ Replace	N	S
		■ Repair		
		Set speed		
	• Seal	- Replace	Р	W
		- Repair		

N Normal operation (production)

P Stop (maintenance, troubleshooting)

## Time interval (TI)

S every shift (8 hours)

W every week

M every month

Y every year

AISHA-CCM Version: A - 2018-10-19 13