



SMS @ group

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Operating Instructions Electrics.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	Fastening	Fasten	Р	Υ
	Damage	■ Replace	Р	М
	(condition)	■ Repair		
	Function	Repair	N	S
	 Unusual noises 	Eliminate the cause	N	М
	• Wear	Replace	Р	М
		Repair		
	Contamination	- Clean	Р	М
Limit switch	Function	 Adjust 	Z	М
		- Replace		
		■ Repair		
Fluid line,	- Leaks	Replace		М
fluid connection		■ Repair		
	Volumetric flow rate	Set volumetric flow rate	N	М
Roller support	Damage	Replace	Р	М
	- Position	Center		6M

AISHA-CCM Version: A - 2018-09-27 13



Mandrel support bearing

Maintenance

Area	Inspection	Action	ОС	TI
	• Wear			М
Sleeves in lever	 Function 	 Replace 	R	3M
	• Wear			
Cylinder	Function	Replace	Ν	S
		■ Repair		
		Set speed		
	 Bearing assembly 	Fasten	Р	Υ
		■ Replace		
		 Repair 		
	Sealing	Replace	Р	М
		 Repair 		

Operating condition (OC)		Time interval (TI)		
N	Normal operation (production)	S	every shift (8 hours)	
Z	Enabling mode	**)W	every week	
Р	Stop (maintenance, troubleshooting)	**)M	every month	
R	Repair	**)Y	every year	
		**) Intervals combined with numbers signify for example:		
		3M= every three months		

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.