

Maintenance

## 7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	<ul><li>Fastening</li></ul>	■ Fasten	Р	Υ
	<ul><li>Damage</li></ul>	<ul> <li>Replace</li> </ul>	Р	6M
	(condition)	■ Repair		
	Function	Repair	N	S
	<ul> <li>Unusual noises</li> </ul>	Eliminate the cause	N	М
	Contamination	Clean	Р	М
Roller barrel surface	Damage	Replace	Р	W
	- Corrosion	Smoothen surface		
	• Wear			
Bearing assembly	Function	Adjust clearance	Р	Υ
		<ul> <li>Replace</li> </ul>		
Shaft seal	Grease lubrication unit	Repair	Р	ЗМ
	- Condition	<ul> <li>Replace</li> </ul>		
Electrical equipment	Cable connections	Repair		М
		Replace		

Operating condition (OC)		Time interval (TI)		
N	Normal operation (production)	S	every shift (8 hours)	
Р	Stop (maintenance, troubleshooting)	**)W	every week	
		**)M	every month	
		**)Y	every year	
		**) Intervals combined with numbers denote for		
		example:		

3M= every three months

## **NOTICE**

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.